

Sealed Silicone Keyboard

MT101

* Please read this user manual carefully before you start using this product.

Antimicrobial

Keyboard with antimicrobial protection is formulated to suppress the growth of odour and stain-causing microorganisms, and is not intended for use as a replacement to proper hygiene or for prevention of infectious illness.

Europe – EU Declaration of Conformity
The product is conformity with all the essential requirements and other provisions of the European Council Directive: Directive 2014/53/EU on Radio Equipment and RoHS Directive 2011/65/EU.



Disposal of waste equipment by user in private household in the European Union



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.



Interface introduction



- Clean mode lock keys (Holding on 5 seconds)
- Backlight on/off
- Turn down the backlight
- Turn up the backlight

Specifications

Dimensions:	382(L) x 132(W) x 14(T) mm
Connection type:	USB
Input voltage:	5V
G.W.:	750Gs
Operating temperature:	-10°C to +60 °C
Storage temperature:	-20°C to +65°C
Compatibility:	Microsoft Windows 11/10/7/Vista/XP/2000/ME/98

General Cleaning Instructions

Spray-Wipe-Spray Method

1. To avoid accidental keystrokes, entering or deleting important data, LOCK the keyboard by turning on "Cleaning mode" switch , holding on 5 seconds
2. Clean the surface of the item by wiping, gently brushing, dipping it or by following the "spray-wipe-spray" protocol outlined as follows. Spray the product with disinfecting spray, wipe away dirt and organic solids with a cloth then spray the product completely again with disinfecting spray, allowing the disinfectant to remain on the product for at least five seconds.
3. Either wipe with dry cloth or shake gently and allow to air dry.
4. UNLOCK the keyboard by turning off "Cleaning mode" switch Holding on 5 seconds.

Sanitising Dip Method

1. To avoid accidental keystrokes, entering or deleting important data, unplug the USB cable from your device before cleaning.
2. Cover the end of the USB cable with the attached USB waterproof cap.
3. Soak and flush the keyboard with approved cleaning agents and disinfectants.
 - ✓ Water temperature should be less than 50° C (120° F) and water should not be deeper than 50 cm.
 - ✓ Recommended cleaning materials: dish washing liquid, non-abrasive cleanser, general purpose cleaner, disinfectant, soap water, rubbing alcohol / surgical spirit.
 - ✓ DO NOT USE any Petroleum based solvents (e.g., Gasoline, Mineral Spirits, Turpentine), Acetone or cleaning solution containing in excess of 10% bleach. Don't use abrasives.
4. Rinse thoroughly to remove any residual cleaning agent.
5. Drying the keyboard.
 - ✓ Unplug the USB waterproof cap, dry of water drops from the USB interface with a tissue.
 - ✓ Dry off with a clean towel.
 - ✓ Do not use a hot-air drier.
 - ✓ Reconnect the keyboard.

Don't plug a wet cable into your computer.